

Installing Railing Posts with Glass Clamps *

Part 1: Installing the Glass Clamps

- 1) Mount all the Glass Clamps using the provided screws and washers without tightening them all the way
- 2) Adjust the Glass Clamps to line up before tightening. In the case of a middle post when there are four Glass Clamps, make sure the top and bottom Glass Clamps are lined up as well as the angle is the desired one (90, 135 or 180 degree). Basically the Glass Clamps have room for up/down and left/right small adjustments
- 3) Repeat steps 1 & 2 to all the Posts of your project

Caution: Wear protective safety glass, working gloves and breathing mask all the time.

© InlineDesign.com

Do not order the Glass before the installation of the Posts in order to take exact measurements.

Part 2: Installing the Posts on the surface

It's preferable to use bolts to screws. Type of bolts differs depending on the surface. i.e. anchor bolts for concrete/cement. Due to the variety of floor surfaces, customers must supply the connecting hardware for the base, i.e., bolts, anchor bolts, etc.

- 1) Skip this step if your Posts have no Base Cover. Lift the Base Cover gently to the Glass Clamp and tape it so it doesn't fall down. Apply the same to all the Posts
- 2) Adjust all the Posts positions on the mounting platform. Make sure all the Posts line up correctly for the glass to mount on them
- 3) Mark your drilling points
- 4) Remove the Posts
- 5) Perform the drilling for the first Post
- 6) Put back the first Post
- 7) It's very important to make sure that the Post is leveled. If needed use some kind of chimes made of wood or rubber material to adjust the leveling. Another option is the use of Stainless Steel washers positioned between the posts and the surface for leveling. Use a level tool on all sides of the post to



ensure proper leveling

- 8) Using a wrench tighten the bolts to the surface (you may want to tape around the post before using the wrench in order to prevent scratching). Usually there is room for small circular adjustments when mounting the glass if needed
- 9) Skip this step if your Posts have no Base Cover. Remove the tape from the Base Cover then lower it gently to the base
- 10) Repeat steps 5 to 9 to all the Posts of your project